

















# Poppenwandelwagen Buggy Doll's Buggy

522.459



Let op: bestudeer deze bouwhandleiding zorgvuldig voor montage. Montage alleen door volwassenen.  
 NOTE: Please read instructions before starting to assemble. Adult assembly required.  
 Important! This item is for indoor use. Check regularly to ensure all parts are secure and no damage has been sustained. If broken discontinue using it. Failure to do may result in injury.  
 Belangrijk! Dit artikel is voor gebruik binnen. Controleer regelmatig of alle onderdelen veilig zijn en geen schade is ontstaan. Indien defect niet meer gebruiken. Bij in gebreke blijven kan dit tot verwondingen leiden.

<b>A</b>  X1	<b>B</b>  X1	<b>C</b>  X1
<b>D</b>  X2	<b>E</b>  195795 Ø20X246 THE RED ONE X1	<b>F</b>  195795 Ø20X246 X4
<b>G</b>  330632 Ø8X352 X2	<b>H</b>  X4	<b>I</b>  X4
<b>J</b>  330594 M8 X4	<b>K</b>  330590 Ø17XØ8.5X2 X8	<b>L</b>  330589 M5X45 X10
<b>M</b>  330840 M5X9 X2	<b>N</b>  330862 M5X18 X2	<b>O</b>  TOOL X1

